

BEFORE YOU BEGIN

1) This is a 12 volt conversion kit.

In other words you will need to replace all electrical components short of the starter motor and the wiper motor (with a 6-volt drop down) on pre-1967 vehicles. This kit will not support 6v components. 12 Volt replacements components are not included in this kit.

2) This is a custom wiring harness.

It is not a factory replacement, or direct fit harness for any year vehicle. Specialized tools are a must. General knowledge of automotive electrical systems is recommended for installation.

3) Disconnect your Battery before beginning.

Prevent accidental shorting and electricution.

4) Once this kit has been installed it is non refundable.

5) Kit will not support auto-stick transmissions, rear defogger, or ignition buzzers.

6) Battery cables are NOT included in this kit.

THIS KIT INCLUDES THE FOLLOWING

Head Light
& Running
Light
Wiring Kit

Ignition &
Starter
Wiring Kit

Turn Signal
& Flasher
Wiring Kit

Speedometer
& Gauge
Wiring Kit

Windshield
Wiper Motor
Wiring Kit

Accessory
Wiring Kit

Loose
Wiring
Terminals
Kit

Aftermarket
Fuse
Panel

Hard Start
Relay &
Harness

Electronic
Flasher

Speedo Turn
Indicator
Light &
Socket